

MOTION ADJUSTABLE
SMART BASE

Existing Bed Frame Install

Depending on the bed frame, it can be possible to use an existing bed frame for an Opera® Adjustable Smart Base. For the Adjustable Smart Base to fit into the bed frame, the bed frame must include the following credentials:

- It must be possible to remove the wooden or metal slats from the bed frame.
- When the slats are removed, the centre of the bed frame should be at floor level with no obstructions i.e. no under-bed drawers.
- There must be a minimum dimension within the bed frame as in the table below for the appropriate bed size.



	Single	Small Double	King Dual	Super King Dual
A	300mm	300mm	300mm	300mm
B	2010mm	2010mm	2010mm	2010mm
C	910mm	1210mm	1510mm	1810mm
D	200mm	200mm	200mm	200mm

If the bed frame fits into all the credentials above, the Adjustable Smart Base can be installed. The steps to install the Adjustable Smart Base are:

1. Assemble the bed frame so that the outer frame is attached. Ensure that there are no slats installed.
2. Lift the Adjustable Smart Base into the bed frame. **It is recommended that at least two people lift the Adjustable Smart Base due to its heavy weight.** Installation can be made easier if the head and foot end are raised to the highest position as the base can be held by the metal platform.